




SPARE PARTS LIST

SCARIFIER

BMP 4000RC, 2022-05




FRAME

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	535 20 27-02	COVER	COVER	1
2	535 24 21-02	COVER	COVER	1
3	533 08 45-01	HINGE	HINGE	2
4	534 66 33-01	LEVEL	LEVEL	1
5	535 11 88-02	BRACKET	BRACKET	2
6	533 62 27-01	SPRING	SPRING	1
7	531 47 12-01	LOCK	LOCK	1
8	535 18 42-02	FRONT COVER	FRONT COVER	1
9	535 11 91-02	BRACKET	BRACKET	1
10	534 60 81-01	BRAKE	BRAKE	1
11	534 40 98-01	CONTROL CABLE	CONTROL CABLE	1
12	537459101	TBD	COVER	1
13	537459201	TBD	ELECTRONIC BOX	1
14	533 28 91-01	KEY	KEY	1
14	533 38 74-01	SWITCH	SWITCH	1
14	533 81 08-01	CORD	CORD	1
15	537459301	TBD	FRAME	1
16	537459401	TBD	LIGHT	2
17	531 46 81-01	KNOB	KNOB	18
18	535 23 43-02	COVER	COVER	1
19	535 25 06-01	BRACKET	BRACKET	1


**BMP 4000 RC
GENERAL & ELECTRIC**



ELECTRICAL

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	535116302	TBD	COVER	1
2	534 66 24-01	LIGHT	LIGHT	1
3	537461301	TBD	COOLER	1
4	531 47 76-01	DOOR	DOOR	1
5	534 73 49-02	OIL TANK	OIL TANK	1
6	534 82 36-01	SEAL	SEAL	1
7	534 73 50-01	COVER	COVER	1
8	537459901	TBD	FILTER	1
9	533 87 28-01	GAUGE	GAUGE	1
10	535 21 91-01	BRACKET	BRACKET	1
11	535145102	TBD	BRACKET	1
12	534 37 78-02	CABLE GUIDE	CABLE GUIDE	1
13	535 21 96-02	BRACKET	BRACKET	1
14	534 29 85-01	MAT	MAT	1
15	535 21 97-02	PLATE	PLATE	1
16	533 28 71-01	SPRING	SPRING	2
17	533 02 92-01	SWITCH	SWITCH	1
18	535 25 18-02	STOP	STOP	1
19	533 94 32-01	ABSORBER	ABSORBER	4
20	533 67 52-02	SUPPORT	SUPPORT	1
21	533 59 52-01	LOCKING PIN	LOCKING PIN	2
22	537460201	TBD	PUMP	1
23	537460001	TBD	PUMP	1
24	537460101	TBD	PUMP	1
25	537460301	TBD	BRACKET	1
26	534468102	TBD	MOTOR	1
27	537460401	TBD	ABSORBER	2
28	535 26 83-02	PLATE	PLATE	1
29	535 26 84-02	PLATE	PLATE	14
30	537460501	TBD	REMOTE CONTROL	1
31	534 83 59-01	ABSORBER	ABSORBER	4




WHEEL ASSY

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	533 13 25-01	BEARING HOUSING	BEARING HOUSING	1
2	533 47 50-01	NUT	NUT	1
3	533 34 57-01	SPACER RING	SPACER RING	1
4	534 31 22-01	BEARING	BEARING	1
5	533 61 69-01	BEARING	BEARING	1
6	534 31 23-01	BEARING	BEARING	1
7	533 67 14-01	SPACER	SPACER	1
8	535 18 68-02	WHEEL BRACKET	WHEEL BRACKET	1
9	534 68 73-01	WASHER	WASHER	4
10	533 73 64-01	CYLINDER	CYLINDER	1
11	534 86 88-01	SPRING	SPRING	2
12	534 69 27-01	CAP	CAP	4
13	535 21 64-02	MOUNTING PLATE	MOUNTING PLATE	2
14	535 14 44-01	PLATE	PLATE	2
15	533 91 17-01	BOLT	BOLT	2
16	533 23 95-01	EYE BOLT	EYE BOLT	3
17	533 40 24-01	BOLT	BOLT	4
18	535 14 43-02	STRIP	STRIP	2
19	534 68 36-01	BOLT	BOLT	4
20	533 24 61-01	BEARING	BEARING	2
21	900 00 00-02	DUMMY PART	DUMMY PART	4
22	533 44 20-01	AXLE	AXLE	1
23	533 23 66-01	WHEEL	WHEEL	1
24	535 24 92-02	STRIP	STRIP	2
25	900 00 00-02	DUMMY PART	DUMMY PART	4
26	534 86 07-01	SPRING	SPRING	1
27	534 40 98-01	CONTROL CABLE	CONTROL CABLE	1

**BMP 4000 RC
DRUMHOUSING, COMPLETE**




HOUSING

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	534 81 97-01	MOTOR	MOTOR	1
2	533 85 11-01	BOLT	BOLT	4
3	534 63 98-01	FLANGE	FLANGE	1
4	537460601	TBD	COUPLING	1
5	534 26 58-01	SCREW	SCREW	1
6	900 00 00-02	DUMMY PART	DUMMY PART	1
7	533 28 88-01	NUT	NUT	1
8	537460701	TBD	MOTOR	1
9	533 85 11-01	BOLT	BOLT	4
10	534 63 98-01	FLANGE	FLANGE	1
11	900 00 00-02	DUMMY PART	DUMMY PART	4
12	534 41 38-01	AXLE	AXLE	1
13	533 24 63-01	COUPLING	COUPLING	1
14	535 16 81-02	HOUSING	HOUSING	1
15	533 47 70-01	GASKET	GASKET	1
16	537460801	TBD	BEARING UNIT	1
17	535 24 44-02	PLATE	PLATE	1
18	533 44 29-01	GASKET	GASKET	1
19	900 00 00-02	DUMMY PART	DUMMY PART	6
20	535 15 01-02	BAR	BAR	2
21	533 83 16-01	ABSORBER	ABSORBER	6
22	533 07 35-01	SCREW	SCREW	4
23	900 00 00-02	DUMMY PART	DUMMY PART	3
24	536 01 98-01	BEARING UNIT	BEARING UNIT	1
25	534 84 14-02	PLATE	PLATE	1
26	900 00 00-02	DUMMY PART	DUMMY PART	4
27	535 24 46-02	PLATE	PLATE	1
28	534 84 42-01	BUSH	BUSH	4
29	534 68 69-01	SCREW	SCREW	4

Ref	Part No	Description	Remark	QTY KIT
30	533 73 90-01	MOTOR	MOTOR	1

**BMP 4000 RC
LH BEARING HOUSE COMPLETE**




BEARING HOUSING

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	533 24 63-01	COUPLING	COUPLING	1
2	534 41 38-01	AXLE	AXLE	1
3	533 25 58-01	SEAL	SEAL	1
4	533 22 05-01	RING	RING	1
5	533 37 11-01	RING	RING	2
6	533 21 84-01	BEARING	BEARING	1
7	533 74 09-01	SEAL	SEAL	1
8	534 31 54-01	BEARING HOUSING	BEARING HOUSING	1
9	537460901	TBD	NIPPLE	1
10	900 00 00-02	DUMMY PART	DUMMY PART	1
11	900 00 00-02	DUMMY PART	DUMMY PART	1
12	533 28 88-01	NUT	NUT	1
13	534 64 95-01	KEY	KEY	1
14	534 52 89-01	DRIVE SHAFT	DRIVE SHAFT	1
15	537460801	TBD	BEARING UNIT	1

**BMP 4000 RC
RH BEARING HOUSE, COMPLETE**




BEARING HOUSING

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	533 74 09-01	SEAL	SEAL	1
2	533 37 11-01	RING	RING	1
3	533 24 80-01	BEARING HOUSING	BEARING HOUSING	1
4	537460901	TBD	NIPPLE	1
5	533 48 50-01	SUPPORT	SUPPORT	1
6	533 21 84-01	BEARING	BEARING	1
7	533 37 11-01	RING	RING	1
8	533 22 05-01	RING	RING	1
9	533 25 58-01	SEAL	SEAL	1

**BMP 4000 RC
DRIVE WHEEL, COMPLETE**




DRIVE WHEEL ASSY

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	534 91 13-01	CAP	CAP	1
2	537461001	TBD	CABLE	1
3	535 07 49-02	WHEEL BRACKET	WHEEL BRACKET	1
4	534 62 03-01	CYLINDER	CYLINDER	1
5	534 42 48-01	PIN	PIN	2
6	900 00 00-02	DUMMY PART	DUMMY PART	2
7	900 00 00-02	DUMMY PART	DUMMY PART	4
8	533 28 07-01	WHEEL MOTOR	WHEEL MOTOR	1
9	535 21 61-02	MOUNT	MOUNT	2
10	533 74 83-01	SCREW	SCREW	12
11	534 93 77-01	WHEEL BRACKET	WHEEL BRACKET	1
12	535 37 80-01	LOCKING PIN	LOCKING PIN	1
13	900 00 00-02	DUMMY PART	DUMMY PART	4
14	534 67 85-01	SCREW	SCREW	2
15	533 78 44-01	NUT	NUT	8
16	535 15 65-02	COVER	COVER	2
17	535 24 39-01	PLATE	PLATE	1
18	535 27 01-02	WHEEL BRACKET	WHEEL BRACKET	1
19	900 00 00-02	DUMMY PART	DUMMY PART	1
20	900 00 00-02	DUMMY PART	DUMMY PART	1
21	534 68 73-01	WASHER	WASHER	1
22	533 23 66-01	WHEEL	WHEEL	1
23	533 29 29-01	HEXAGON LOCKING NUT	HEXAGON LOCKING NUT	4
24	537461101	TBD	WHEEL	1

**BMP 4000 RC
DRUMS**



DRUM

BMP 4000RC, 2022-05

Ref	Part No	Description	Remark	QTY KIT
1	533 12 77-01	TOOL	TOOL	60
1	533 33 47-01	UNIT	UNIT	60
2	534 82 01-01	DRUM	DRUM	1
3	534 68 23-01	EYE BOLT	EYE BOLT	2
4	533 12 77-01	TOOL	TOOL	116
5	534 82 00-01	DRUM	DRUM	1
6	534 68 23-01	EYE BOLT	EYE BOLT	2
7	537461201	TBD	PLATE	2
8	533196602	TBD	DRUM	1
9	533 71 63-01	TOOL	TOOL	60
10	533 86 72-01	SPACER RING	SPACER RING	1
10	534 85 67-01	SPACER RING	SPACER RING	1
10	534 85 68-01	SPACER RING	SPACER RING	1
11	533 59 16-01	SCREW	SCREW	10
12	534 68 23-01	EYE BOLT	EYE BOLT	2
13	534 75 56-01	TOOL	TOOL	1
14	534 61 29-01	HANDLE	HANDLE	2
15	535 16 78-01	AXLE	AXLE	1
16	535 16 79-01	PLATE	PLATE	1
17	535 16 80-01	SUPPORT	SUPPORT	2
18	533 66 08-01	DRUM	DRUM	1
19	533 86 76-01	DRUM	DRUM	1
20	533 19 66-01	DRUM	DRUM	1
21	534 85 68-01	SPACER RING	SPACER RING	1
22	534 85 67-01	SPACER RING	SPACER RING	1
23	533 86 72-01	SPACER RING	SPACER RING	1