

# Fuse Installation for LineLazer V 250SPS and 250DC Self-Propelled Line Striper

3A5189A

EN

*For initial use - fuse installation.*




## Important Safety Instructions

Read all warnings and instructions in this manual and in the sprayer operation manual. Save these instructions.

## Fuse Installation Process

1. Remove fuse cover (1).
2. Use needle-nose pliers (2) to install new fuse (3).
3. Replace cover (1).



# Graco Information

For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

**TO PLACE AN ORDER**, contact your Graco distributor or call 1-800-690-2894 to identify the nearest distributor.

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A5189

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**  
**Copyright 2017, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)  
Revision A, April 2017